

CAT[®] TRANSMISSION TOOLING – 416E / 420E

REPAIR OPTION: Rebearing and Resealing Transmission

DIRECT DRIVE TRANSMISSION

MACHINE MODELS: 416E / 420E

Part Number	Quantity	Description
155-3597	4	WHEEL CHOCK
1U-9745	1	JACK
180-3034	2	REPAIR STAND SET
8S-7615	2	PIN
4C-6486	2	STAND
8S-7641	2	TUBE
8S-8048	2	SADDLE
1U-9330	1	HYDRAULIC JACK
1U-7505	1	HYDRAULIC JACK
1U-7558	2	MOUNTING ADAPTER GROUP
1U-5750	1	ENGINE STAND
6V-2157	2	LINK BRACKET
6V-3009	1	CROSSBAR
126-7181	4	SLIDING PLATE
6V-4832	1	FORCING SCREW
8H-0663	1	BEARING PULLER GROUP
126-7177	2	PULLER LEG
126-7178	2	PULLER LEG
126-7179	2	PULLER LEG
4C-3652	1	SPRING COMPRESSOR
1U-6400	1	THREE JAW PULLER
8B-7551	1	BEARING PULLER GROUP
1P-1859	1	SNAP RING PLIERS
8T-5096	1	INDICATOR
1P-0510	1	DRIVER GROUP
4C-9507	1	RETAINING COMPOUND
1U-8846	1	GASKET SEALANT
1H-9721	1	EXPANSION PLUG

BUILT FOR IT.[™]

cat.com

© 2017 Caterpillar. All Rights Reserved. CAT, CATERPILLAR, BUILT FOR IT, their respective logos, "Caterpillar Yellow," the "Power Edge" trade dress, as well as corporate and product identity used herein, are trademarks of Caterpillar and may not be used without permission.

